

# 8 Button Wireless Transmitter

## **MT-8 Wireless Transmitter**

The MT-8 wireless Transmitter is 2.87" x 4.65" in size. This industrial unit can be mated with NWI's current line of wireless receivers. All MT-8 transmitters come from the factory with a pre-install address (1 in 16 million). An optional rubber boot that encloses the transmitter is also available from NWI. The MT-8 will transmit up to 8 individual signals to the wireless receiver using buttons 1 thru 8.

### **Setting up the MT-8 to transmit to an existing receiver:**

- Remove the cover of the receiver box if necessary.
- Power up the receiver.
- Depress the black programming button, and the red LED will begin to flash for 15 seconds.
- While the red LED is flashing, press and release only 1 of the 8 buttons on the MT-8 transmitter.
- Wait until the red LED stops flashing on the Receiver (approx. 15 seconds).
- As a test, now depress buttons 1 thru 8 and the red LED on the receiver should light when a button is depressed. Once tested, replace cover if necessary. The MT-8 is now ready for use.

